

# ST wall fixation Installation instructions



## How to set it up

The ST mount is designed for a single column. It connects to the threaded faucet with the provided KCR adapter.

1. Attach it to the wall vertically with the screws and plugs provided. Place it as close as possible to a threaded water tap (we recommend adjusting it upwards).
2. Screw the straight end caps at the top and bottom of the mount (seal it with the provided Teflon tape).
3. Insert the outlet pipe (cut to size) at the bottom of the mount.
4. Insert the inlet pipe at the top of the mount.
5. Install the KCR quick connector on the threaded tap of your water supply.
6. Unpack the ion exchanger. Clean the black neoprene washers carefully with alcohol (the washers are provided with each column), dry them and insert them into the column support cylinders.
7. Insert the bottom tip of the column into the cylindrical hole at the bottom of the mount. Straighten the column, insert it into the upper hole and hand tighten the lock nut while locking the fastener.



**A nut of this diameter can generate considerable force, even when hand-tightened.** Tighten the nuts gradually and moderately, overtightening can damage the fastener.